

Hanger Sizing Guide

Minimum Hanger Inside Hanger Diameters (In Inches)
 To Fit Standard Insulated Pipe Supports

Iron Pipe	<u>Insulation Thickness</u>			
	X 1/2"	X 1"	X 1-1/2"	X 2"
1/2	2.000	3.000	4.125	5.125
3/4	2.250	3.000	4.125	5.125
1	2.500	3.625	4.625	5.625
1-1/4	3.000	3.625	5.125	5.625
1-1/2	3.155	4.125	5.125	6.750
2	3.625	4.625	5.625	6.750
2-1/2	4.125	5.125	6.750	7.750
3	4.625	5.625	6.750	7.750
4	5.625	6.750	7.750	8.750
5	6.750	7.750	8.750	9.750
6	7.750	8.750	9.750	10.875
8	9.875	10.875	11.875	12.875
10	12.000	12.875	14.250	15.250
12	14.000	15.250	16.250	17.250
14	15.125	16.375	17.375	18.375

Copper Tube	<u>Insulation Thickness</u>			
	X 1/2"	X 1"	X 1-1/2"	X 2"
5/8	2.000	3.000	3.500	4.625
7/8	2.000	3.000	4.125	5.125
1-1/8	2.250	3.000	4.125	5.125
1-3/8	2.500	3.625	4.625	5.625
1-5/8	3.000	3.625	5.125	5.625
2-1/8	3.625	4.125	5.125	6.750
2-5/8	4.125	4.625	5.625	6.750
3-1/8	4.625	5.125	6.750	7.750
4-1/8	5.625	6.750	7.750	8.750
6-1/8	7.750	8.750	9.750	10.875

NOTE: Hanger inside diameters must be large enough to accommodate the insulation wall thickness and the steel protection shield thickness. **Bold Type** indicates insulation sizes where outside diameters **do not change** as the pipe size changes.

Units comply with ASTM C-585 dimensional standards, subject to normal manufacturing tolerances.